





Parts List

Model CH30000

www.hoover.com



FLOOR-EQUIPMENT-PARTS.COM



Ref No.	Part No.	Description
1	46383258	Power Cord
2	162059AG	Diffuser Door
3	162062AY	Hinge Pin
4	43662023	Bag Assembly
5	59156690	Housing - Right
6	42227039	Bag Door
7	162083JM	Secondary Filter
8	59156688	Pressure Pad
9	34366001	Diffuser
10	59135400	Motor Assembly
11	37922002	Terminal Shield
12	38421012	Switch Button
13	28177006	Switch
14	27666702	Switch Terminal
15	59135401	Motor Terminal
16	012227--	Wire Terminal
17	36215015	Cord Protector
18	21447043	Screw
19	59156689	Housing - Left
20	59156694	Screw - M4 x 18 x 70mm
21	48615012	Cord Storage Strap
22	33153002	Strap Hook
24	48615001	Carrying Strap Assembly
25	38663010	Disposable Bag Support Tube
26	046550AG	Belt
27	4010038N	Type N Paper Bag - 5 Pack
28	4341401P	Rug / Floor Nozzle
29	38617017	Crevice Tool
30	43414073	Floor Brush
31	43414057	Furniture Nozzle
32	43434239	Hose Assembly Complete - 5.5"
33	43453027	Extension Tube Assembly
34	43414064	Dusting Brush