


Wide Area Squeegee

Model No:
470000
470033



FLOOREQUIPMENTPARTS.COM


Optional Squeegee
Assembly
15/20 Gallon
Poly Tanks

OPERATION

SERVICE


PARTS

CARE



Revised 6/02

Minuteman[®]



PARTS LISTING

ITEM	PART	QTY	DESCRIPTION	ITEM	PART	QTY	DESCRIPTION
1	430085	2	Squeegee Bumper Wheel	16	711524	6	WSR-Wave
2	430073	1	Gasket	17	711544	6	WSR-Helical 1/4
3	430078	1	U Profile	18	711594	4	WSR-Flat
3A	210024	1	U Profile (470033)	19	711713	6	Retaining Ring-E
4	430079	1	Squeegee Casting Assembly	20	712041	2	BLT-SDER 1/4-20 x .44 x .37
4A	210023	1	Squeegee Casting Assembly (470033)	21	750137	1	Bkt Arm Squeegee Asy Left
5	11-145	1	Squeegee Blade	22	750138	1	Bkt Arm Squeegee Asy Right
5A	210065	1	Squeegee Blade (470033)	23	750139	1	Squeegee Mtg. Bkt. Asy
6	470001	1	Rear Brace	24	750140-1	1	Vac Hose Assembly
7	470005	1	Lever Lock Asy	25	750689	2	Stud, Adjusting
8	470007	1	Axle Squeegee Asy	26	762256PLT	2	Nut Adj. LH
9	430074	6	Adjusting Knob	27	762257PLT	2	Nut Adj. RH
10	711203	4	BLT-HH 1/4-20 x .62	28	807384	1	Rod Handle
11	711206	2	BLT-HH 1/4-20 x .87 STPL	29	807385	1	Knob Handle
12	711377	2	Nut-Lock 1/4-20	30	829052	2	Flanged Bushing
13	711420	2	Nut-Hex Jam 5/16-18 STPL	31	710389	2	SCR-MC 1/4 -20 x 2.00 SS
14	711505	2	WSR-Flat 1/4	32	712517	4	SCR-MC 8/32
15	711506	2	WSR-Flat 5/16 STPL	33	430076	2	Squeegee End Cap

INSTALLATION INSTRUCTIONS 470200 SQUEEGEE ASSEMBLY

1. Turn existing tank upside down and remove both wheels (A) by removing snap ring 19 from existing axle.
2. Remove screws (B) from existing axle and remove old axle.
3. Reinstall wheels onto new axle assembly with new E clip provided.
4. Install new axle - squeegee assembly to bottom of tank using existing screws "B" and tighten securely.
5. Turn tank assembly to upright position and remove washers and nuts (C) from handle assembly. Mount Item 7 over existing bolts. Use lockwasher and nut to tighten Item 7 securely in place.
6. Slide Item 28 through Item 7 and mount lift arm to Item 21 with bolts supplied.

ADJUSTMENTS

1. Angle of squeegee assembly can be adjusted if needed, by loosening nut 13 and turning item 25. Both sides may need adjusting so that squeegee blade is parallel to floor in down position.
2. 15 Gallon Units Only.
3. Vac hose assembly, Item 24, should be shortened by 4" to remove excess length.

LIMITED WARRANTY

Minuteman International, Inc. warrants to the original purchaser/user that this product is free from defects in workmanship and materials under normal use and service for a period of three years from date of purchase. In addition, Minuteman International, Inc. will, at its option, honor labor warranty claims for the first 12 months from date of sale, provided such claims are submitted through and approved by factory authorized repair stations. Minuteman International, Inc. will, at its option, repair or replace without charge, except for transportation costs, parts that fail under normal use and service when operated and maintained in accordance with the applicable operation and instruction manuals.

This warranty does not apply to normal wear, or to items whose life is dependent on their use and care, such as belts, cords, switches, hoses, rubber parts, electrical motor components or adjustments. Parts not manufactured by Minuteman International, Inc. such as engines, batteries, battery chargers, hydraulic pumps, and tires are covered by and subject to the warranties and/or guarantees of their manufacturers. Please contact Minuteman International, Inc. for procedures in warranty claims against these manufacturers.

Special warning to purchaser — Use of replacement filters and/or prefilters not manufactured by Minuteman International, Inc. or its designated licensees, will void all warranties expressed or implied.

A potential health hazard exists without exact original equipment replacement.

All warranted items become the sole property of Minuteman International, Inc. or its original manufacturer, whichever the case may be.

Minuteman International, Inc. disclaims any implied warranty, including the warranty of merchantability and the warranty of fitness for a particular purpose. Minuteman International, Inc. assumes no responsibility for any special, incidental or consequential damages.

This limited warranty is applicable only in the U.S.A. and Canada, and is extended only to the original user/purchaser of this product. Customers outside the U.S.A. and Canada should contact their local distributor for export warranty policies. Minuteman International, Inc. is not responsible for costs or repairs performed by persons other than those specifically authorized by Minuteman International, Inc. This warranty does not apply to damage from transportation, alterations by unauthorized persons, misuse or abuse of the equipment, use of non-compatible chemicals, or damage to property, or loss of income due to malfunctions of the product.

If a difficulty develops with this machine, you should contact the dealer from whom it was purchased.

This warranty gives you specific legal rights, and you may have other rights which vary from state to state. Some states do not allow the exclusion or limitation of special, incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.

Minuteman[®]

World Headquarters
Minuteman International, Inc.
111 South Rohlwing Road
Addison, Illinois 60101

Minuteman Canada, Inc.
2210 Drew Road
Mississauga, Ontario
L5S 1B1

(630) 627-6900
FAX (630) 627-1130

(905) 673-3222
FAX (905) 673-5161

987317
Printed in U.S.A.